

034763 0602560

FIG. 1





FIG. 2



004760" 06032560

FIG. 3




FIG. 4




FIG. 5




FIG. 7




FIG. 8





FIG. 9

900



AUDIO SESSION COMMANDS

LIVE MODE

CHANNEL SELECT (#)
 RESCAN CHANNELS (*)
 RECORD [R1/2/3 TO RECORD 5/10/15 MINS.]
 MUTE
 STOP

ON DEMAND MODE

GENRE SELECTIONS
 REWIND TO START OF ITEM
 SKIP TO NEXT ITEM [WITH PLAYLISTS]
 REPEAT
 PAUSE/RESUME ITEM
 STOP



SELECTIONS DEPEND ON WHAT MODE YOU ARE IN

LIVE MODE:

DETECT COUNTER IN SCAN PLAYBACK
 * MAIN MENU
 R1/2/3 RECORD 5/10/15
 # MUTE ON/OFF
 0 STOP (HANG UP)


ON-DEMAND:

SELECT GENRE
 B REWIND
 F FORWARD TO NEXT ITEM
 R REPEAT
 #/# PAUSE/RESUME
 0 STOP
 * MAIN MENU

FIG. 10*FIG. 11*

004760" 96952560

FIG. 12



[illegible]